

Tensorgrip®



L14

CONTACT ADHESIVE

TensorGrip® L14 is a spray-on contact adhesive designed for the furniture industry and for bonding various materials to sheets of wood-based panels, metal and some hard plastics. Its stickiness and PSA properties also make it ideal for foams, fabrics, fibrous materials and many other porous and non-porous substrates.


ADVANTAGES

- High solids content.
- Good thermal resistance.
- Easy application control.
- Economic.

Exclusive to Meblopol Sp. z o.o.

TECH DATA

SQUARE METRE COVERAGE (m²)*:



APPLICATION:



2 sided

OPEN TIME**:



Up to 40 mins

SUITABLE FOR:



Standard Laminate



Wood Build-ups



MDF



Edging

FLASH-OFF*:



1 - 3 mins

COLOUR:



Clear

PROPERTIES:



Web Spray

*consult the Spray Manual for a more detailed tutorial on the bonding process.

**depending on ambient temperature.

CHEMICAL TECHNICAL DATA

Viscosity	300Cps
Total dry matter content	27%
Colour	Clear
System Flammability	Flammable adhesive in a flammable propellant
Shear	> 150 p.s.i.
Peel	Not available
Stretching (peel test at an angle of 180 °)	> 25 p.s.i.
Delamination temperature (SAFT) 100grams	>100°C
Flash-Off	1 - 3 minutes depending on temperature and humidity
Open time	Up to 40 mins
Shelf Time	18 months from date of manufacture

HANDLING & STORAGE

- Consult Safety Data Sheet prior to use.
- DO NOT expose to temperatures exceeding 50°C/122°F.
- Store at temperatures between 10°C and 25°C.
- Avoid exposing aerosol containers to high temperatures or direct sunlight.
- Keep away from heat, hot surfaces, sparks, open flames, and other ignition sources.
- Shake well before use.
- To prevent nozzle from blocking, turn can upside down, press nozzle until spray is clear of adhesive.
- Replace cap after use to protect actuator / valve.
- Use only in a well ventilated area.
- Always test product to determine suitability for your particular application prior to use in production.

DIRECTIONS FOR USE

- This product is designed to be applied to two surfaces to be bonded together. For best results, the temperature of the adhesive and the surfaces being bonded should be between 60 °F - 80 °F (16 °C - 27 °C).
- Use with adequate ventilation.
- Prior to use, check compatibility by spraying a small test patch of the adhesive on the substrate. This product may degrade some substrates.



1. SHAKE WELL BEFORE USE.



2. Make sure that surfaces are clean, dry and free from dirt, dust, oil, loose paint, wax or grease, etc.



3. Spray about 10-20 cm (4" – 8") away at a 90° angle to the surface, applying a uniform, even coat of adhesive to obtain 80% to 100% coverage of the surface.



4. If necessary, spray another coat of adhesive in areas that appear to need more adhesive. Spray surfaces vertically and horizontally.



5. Allow 1 - 3 minutes for adhesive to tack off until no adhesive transfers to the knuckle when touched.




6. Adhere surfaces and press together with adequate pressure. Allow 24 hours for the adhesive to fully cure.

7. To prevent nozzle from blocking, turn can upside down press nozzle until spray is clear of adhesive. If nozzle becomes blocked, the adhesive can be removed with a solvent such as lacquer thinner or acetone.

COVERAGE



COVERAGE TOO LIGHT



COVERAGE TOO HEAVY



CORRECT APPLICATION = 20 dry gms/sqm